

SNO-KONE MACHINE

OPERATING INSTRUCTIONS

Ice Requirements: Cube or Block ice can be used. For block ice break block into pieces 3 to 4 inches in size.

1. Switch the motor on
2. Wait for the motor to come to full speed
3. Fill the gooseneck within an inch of the top with ice cubes or block ice (3" to 4"). The larger the pieces the better the snow.
4. Push the pusher handle down against the ice in the gooseneck. Apply firm even pressure to make the best snow. You may find that you need to relieve the pressure 2 to 3 times during a cycle. Over pressure will stall the motor. Too much pressure will result in snow that is coarse; too little pressure will result in snow that is mushy.
5. Never allow any foreign or metallic objects around the shaver area.
6. Do not place hands or fingers in gooseneck chute (shaver area). Chute contains rotating blades that could cause serious injury.
7. When you are all finished:
 - PLEASE CLEAN THE SNO-KONE MACHINE SCOOPS AND PUMPS WITH HOT SOAPY WATER TO REMOVE ALL THE SUGAR.
 - WIPE ENTIRE CABINET INSIDE AND OUT TO REMOVE ANY SNO-KONE SYRUP THAT MAY HAVE SPILL OR SPLATTERED
 - DO NOT USE ANY CHLORINE BASED PRODUCTS TO CLEAN STAINLESS STEEL SURFACES!

Extra syrup can be mixed in a 4 to 1 ratio to make a flavored drink

PUMPS FOR FLAVORING MUST BE RETURNED WITH MACHINE.

THERE WILL BE A \$25.00 CLEANING FEE FOR ALL MACHINES RETURNED UNCLENED